


GUÍA RÁPIDA DE USUARIO

V.2.0



1. INTERCOMUNICADOR



ENCENDER
Suba el switch a posición encendido.
Luz: verde



HABLAR
A volumen normal.
Luz: naranja



ESCUCHAR
Al interlocutor a través del parlante interno.
Luz: verde




APAGAR
Baje el switch a su posición central.
Luz: apagada

2. SIRENA DE EMERGENCIA

ENCENDER
Baje el switch a posición Siren.
Luz: roja




APAGAR
Suba el switch a su posición central.
Luz: apagada




5. SILENCIAR



Silencia la reproducción en la unidad externa.
Luz: verde intermitente




4. VOLUMEN EXTERNO
Ajusta el volumen de reproducción en la unidad externa.




3. VOLUMEN INTERNO
Ajusta el volumen de reproducción en la unidad interna.

RECOMENDACIONES





Para reducir el alcance del micrófono, curve el cuello. Forzar o amarrar el micrófono puede causar daños irreversibles.



Manipule el micrófono por el cuello en vez de por el extremo.


LIMPIEZA Y MANTENIMIENTO

- Limpie las superficies con un paño humedecido con agua jabonosa o alcohol, y remueva la humedad con un paño seco.
- No utilice solventes sobre el producto.
- Verifique periódicamente que los accesorios de montaje están correctamente adheridos. Si es necesario, aplique pegamento.



QUICK USER GUIDE

V.2.0



1. INTERCOM



TURN ON
Pull up the switch to the ON position.
Light: green



SPEAK
At a normal volume.
Light: orange



LISTEN
To the outside audio on the internal speaker.
Light: green




TURN OFF
Push down the switch to its middle position.
Light: off

2. EMERGENCY SIREN

TURN ON
Push down the switch to Siren.
Light: red




TURN OFF
Pull up the switch to its middle position.
Light: off




5. MUTE



Mutes the audio reproduction on the external unit.
Light: blinking green




4. EXTERNAL VOLUME
Adjust the reproduction volume on the external unit.



3. INTERNAL VOLUME
Adjust the reproduction volume on the internal unit.

RECOMMENDATIONS



To shorten the length of the microphone, curve the neck. Forcibly bending the microphone can cause irreversible damage.



Handle the microphone by the neck and not by the tip.

CLEANING AND MAINTENANCE

- Clean the surfaces with a cloth slightly dampened with soapy water or alcohol, and remove the moisture with a dry cloth.
- Do not use any sort of solvent on the product.
- Periodically check that the mounting accessories are properly attached and apply glue if necessary.

